



**Eddie Bauer® Weather-Resist Soft Shell Jacket.  
EB538**

**PRODUCT MEASUREMENTS**

	XS	S	M	L	XL	2XL	3XL	4XL
Chest Width	19 1/4	20 3/4	22 1/4	23 3/4	25 1/4	26 3/4	28 3/4	30 3/4
Body Length at Back	26 1/4	27 1/4	28 3/8	29 1/2	30 5/8	31 3/4	32 3/8	33
Sleeve Length	34 1/4	35	35 3/4	36 1/2	37 1/4	38	38 3/4	39 1/2

**CHEST WIDTH**

Measured across the chest one inch below armhole when laid flat.

**BODY LENGTH AT BACK**

Measured from high point shoulder to finished hem at back.

**SLEEVE LENGTH**

Start at center of neck and measure down shoulder, down sleeve to hem.